

# Otis Everlast™ 7.5

*Note: Twin beds do not utilize the center support rail shown.*

*Note: King beds utilize 2 center support rails and 4 long wood screws.*

Assemble one **Side Rail** and two **End Rails** as shown in **Fig. 1**.

Install **Center Rail(s)** (if applicable) into the pocket on the inside of the **End Rail** as shown in **Fig. 2**.

Slide all **Slats** into routed pockets on **Side Rail**, being sure to put the slat with a hole in each end into the center pocket.

Install final **Side Rail**, making sure all slats fit into pockets.

After about 60 days, check all screws and bolts for tightness and tighten as necessary. Check all screws and bolts for tightness yearly after that.

Parts List	
8	barrel nuts
8	machine screws
2	short wood screws
2	long wood screws ( <b>Full and Queen beds only</b> )
<b>OR</b>	
4	long wood screws ( <b>King beds only</b> )
1	allen wrench

